

# TECHLIFE

## Original display settings - TECHLIFE X9

1. How to enable the change of settings? Just hold the scooters on the attached display simultaneously two buttons. POWER (red) and MODE.
2. How to change programs in the settings? Press the POWER button (red), on the display will switch from P01 to P20.
3. How to edit a given program? Press MODE to the value of interest.

### Factory setting for Techlife X9 electric scooter

- P01 - 003 Brightness of the display backlight
- P02 - 000 Unit of measure km / miles
- P03 - 072 Voltage
- P04 - 005 Time until automatic switch off
- P05 - 000 No function used
- P06 - 11.0 Wheel diameter
- P07 - 028 Magnets in the engine
- P08 - 100 Power limit
- P09 - 000 Start from zero / start to push away
- P10 - 000 No function used
- P11 - 001 Electric brake
- P12 - 005 Acceleration
- P13 - 000 No function used
- P14 - 000 No function used
- P15 - 56.0 Cut-off voltage of the controller
- P16 - 000 Reset to ODO
- P17 - 000 Cruise control (1 - on, 0 - off)
- P18 - 000 No function used
- P19 - 000 No function used
- P20 - 004 No function used

**Techlife is not responsible for any incorrect settings that may occur damage an electric vehicle. You make all changes at your own risk.**